

Sealing thermomanometer with PTFE tape

For sealing off the thermomanometer (104565).

This thermomanometer must be sealed between the two brass threads and between the brass and plastic threads with PTFE tape.

NOTE: Always scrape off brass shavings so that the band does not get caught (risk of leakage)!!! Do not seal too thick and leave the first turn of the thread loose, especially on the plastic side, otherwise there is a risk of tearing the tape.

